



ALLIGATOR® STAPLE GOLD CLASS™ Installation Tool

Power Assisted Tool Improves Consistency and Reduces Installation Time.

Faster.

The air operated power driver allows belt fabricators to install Alligator® Ready Set™ Staple plates with quick and effortless trigger pulls. This simple installation process allows for splices to be installed quickly and consistently, regardless of operator skill and experience.

Easier.

Not only is the installation process easy, it is virtually error-proof. The patent pending drive punch has been designed to seat the front edge of the fastener plate down for proper compression, while at the same time the fastener loops remain protected. With hammer installation, fastener loops can get crushed with accidental hammer blows, resulting in problems with pin insertion.

Safer.

By eliminating the need to hammer install the fasteners, the Alligator Staple Gold Class tool reduces the risk of repetitive motion injuries. It also reduces operator fatigue associated with hammer installing numerous splices throughout the day.

Smarter.



Features and Benefits



Profiled front edge of the drive punch creates proper compression set of the front edge of the fastener plate.



*Initial Drive Base:
Fasteners and belt are inserted into the Initial Drive Base where the pre-staked staples are driven through the belt with simple trigger pulls.*



*Final Set Base:
After the fasteners are initially set, move belt splice to the Final Set Base where the staples receive their final set and the compression fit is obtained.*

ALLIGATOR® STAPLE GOLD CLASS™ Installation Tool

Ordering Information		
Description	Ordering Number	Item Code
Alligator® Staple Gold Class™		
Power Driver	RS-GOLD-DRIVER	55541
Initial Drive Base		
6" Initial Drive Base	RS-GOLD-INITIAL-6	55542
12" Initial Drive Base	RS-GOLD-INITIAL-12	55543
24" Initial Drive Base	RS-GOLD-INITIAL-24	55544
36" Initial Drive Base	RS-GOLD-INITIAL-36	55548
48" Initial Drive Base	RS-GOLD-INITIAL-48	55551
Final Set Base		
6" Final Set Base	RS-GOLD-FINAL-6	55545
12" Final Set Base	RS-GOLD-FINAL-12	55546
24" Final Set Base	RS-GOLD-FINAL-24	55547
36" Final Set Base	RS-GOLD-FINAL-36	55549
48" Final Set Base	RS-GOLD-FINAL-48	55552
Replacement Parts		
Guide Block	ST7-5	55554
Punch	ST7-9	55555
Wear Plate (Final Set Base)	ST7-29	55556
Regulator Hose Assembly	ST7-34	55561
Safety Guard	ST7-35	55562



2525 Wisconsin Avenue • Downers Grove, IL 60515-4200 U.S.A.

Telephone: (630)-971-0150 • Fax: (630)-971-1180 • E-mail: info@flexco.com • Web: www.flexco.com

Australia: 61-2-9680-3322 • China: 86-21-33528388 • England: 44-1274-600-942
Germany: 49-7428-9406-0 • Mexico: 52-55-5674-5326 • South Africa: 27-11-608-4180

©2008 Flexible Steel Lacing Company. Alligator® is a registered trademark. Gold Class™ and Ready Set™ are trademarks. 01/08-5. For Reorder: X2088

